

T4T - Simple Current Programming

Please note:

All information in this guide has been prepared with great care. OSRAM, however, does not accept liability for possible errors, changes and/or omissions. Please check www.osram.com or contact your sales partner for an updated copy of this guide. This technical application guide is for information purposes only and aims to support you in tackling the challenges and taking full advantage of all opportunities the technology has to offer. Please note that this guide is based on own measurements, tests, specific parameters and assumptions. Individual applications may not be covered and need different handling. Responsibility and testing obligations remain with the luminaire manufacturer/OEM/application planner.

Table of content

1 About Tuner4TRONIC – Simple Current Programming Tool	2
1.1 Purpose and Application.....	2
1.2 Files Types	5
1.3 Workflow between the different T4T Versions	5
1.4 System Requirements	6
1.5 Programming Interfaces	7
1.6 Preparing a driver with DALI interface for programming	8
1.7 Preparing a driver with NFC interface for programming	9
1.8 Software Installation	10
2 Using T4T – Simple Current Programming Tool	10
2.1 Start Page	10
2.2 Programming Page: Configuration	12
2.3 Programming Page: Programming	14
2.4 Report Page	16
2.5 Tools Page	17

1 About Tuner4TRONIC – Simple Current Programming Tool

1.1 Purpose and Application

The Tuner4TRONIC Simple Current Programming Tool (T4T-S) allows output current setting in OSRAM wide range LED drivers via NFC instead of LEDset and stick to default settings with any other functionality provided with OSRAM drivers. T4T-S can be operated without permanent internet connection – though it is recommended to update driver database manually, in case of no internet. T4T-S does not require creating production files, since it reads data from a sample driver and sets output current in drivers of the same type.

Since no validation rule is applied by the tool - other than checking min/max limits – the user needs to ensure, that output current values to not interfere with other settings in the driver (e.g. DALI settings, CLO, Tuning Factor, ..). Therefore, it is recommended to use T4T-S with blank drivers with default settings only. Please also note, that programming via DALI interface is not supported by T4T-S. PW setting with T4T-S is recommended to avoid reprogramming by unauthorized persons, since exceeding rated current of the light engine may cause defects in the luminaire.

Please explore the full functionality of LED drivers by using T4T tool chain with T4T-Configurator, T4T-Production and T4T Field app. Tuner4TRONIC tools can be downloaded from www.osram.com/T4T.

The Tuner4TRONIC (T4T) software suite allows luminaire manufacturers to program OSRAM drivers via DALI and/or NFC in a simple, fast, reliable and cost-effective way, speeding up the production process. [Click here to watch a short video that gives a great overview about Tuner4TRONIC.](#)



This software consists of different modules according to the environment of use:





Tuner4TRONIC Configurator

With this web based browser application luminaire designers can configure LED drivers by setting parameters such as output current, dimming levels, constant lumen output, operating modes and much more. Thanks to its multi-level password system, Configuration Lock protects LED drivers against unauthorized changes while service technicians can still be granted access rights for selected features.


Once the configuration has been completed, the settings are exported as an encrypted read-only production file and transmitted to the production line.

www.tuner4TRONIC.com



Tuner4TRONIC Production

Factory workers can easily load encrypted production files in order to start automatic programming for the fast mass production of LED drivers. Provides a multilingual user interface.






Tuner4TRONIC Machine

The DLL and command line tools enable to integrate OSRAM LED driver programming into automatic programming stations in the production line.




Tuner4TRONIC REST API

While the Configurator, Development and Production versions provide the users an intuitive graphical interface, the API („Application Programming Interface“) provides software developers a collection of functions and tools to create luminaire configurations automatically. Typically, the API is used to create luminaire files when a new order is available in the ERP system. The API is based on modern standards (REST) and conventions, comes with a comprehensive documentation and must be integrated into your system by a software developer (OSRAM does not provide ERP system integrations).



Tuner4TRONIC Simple Current Programming

The simple current programming tool is a PC based tool that allows programming driver output current without creating production files. The user can read data from a driver edit output current and upload current setting to drivers of the same type. The tool also supports setting password protection





Tuner4TRONIC Field

T4T-Field is an app for smartphones that can program OSRAM outdoor OT 1DIM and OT 4DIM as well as indoor OTi DALI Compact LED drivers via NFC - wireless and without mains-voltage.

The app can change the light output and the dimming levels of the driver. In addition, a driver configuration can be copied to another driver in a breeze.

[Click here to download the app from Google Play \(Android version\)](#)

[Click here to download the app from the App Store \(iPhone version\)](#)

[Click here to download the dedicated manual for T4T-Field](#)



1.2 Files Types

Tuner4TRONIC Development uses different file types:

- Tuner4TRONIC production file = .osrtup
- Driver description file = .osrtud
- Driver data (raw format) = .osrtur
- Password file = *.osrpwd
- Tuner4TRONIC luminaire project file = .osrtul (phased out)

1.3 Workflow between the different T4T Versions

The luminaire product manager/designer creates his desired configuration (e.g. setting the operating current, CLO and dimming) using T4T Configurator. Our optional T4T API allows to create luminaire and production files directly from an ERP system removing the need to create those files manually. When the configuration is finished, a read-only *.osrtup production file is exported and sent to the assembly line.

At the assembly line, the production file is loaded using T4T Production and the mass programming can start. Alternatively, T4T Machine (DLL and command line tools) can be used to integrate with automatic programming and testing stations.



1.4 System Requirements

The minimum system requirements:

- 1 GB main memory
- Windows 7 (both 32 or 64-bit), Window 8 / 8.1 (both 32 or 64-bit), or Windows 10 (both 32 or 64-bit) latest SP installed
- 100 MB hard disk memory
- Monitor with a resolution of 1024x768 pixels, the recommended zoom factor is 100%
- one free USB 2.0 port for Programming Interface

1.5 Programming Interfaces

To program a luminary containing an OSRAM driver, a programming interface (suitable for the used driver) is needed:

[1] Driver with DALI interface
(multi and/or single programming)

DALI magic



[2] Driver with NFC interface
(only single programming)

FEIG ISC.PRH101



FEIG CPR30



FEIG ISC.MR102
(separate antenna
ISC.ANT310/310 needed)



FEIG ISC.LR1002
(separate antenna
ISC.ANT310/310 or
ISC.ANT800/600 needed)



[3]

FEIG ISC.ANT310/310



FEIG ISC.ANT800/600




The Tuner4TRONIC is capable to handle more than one programming interface connected to the same PC

1.6 Preparing a driver with DALI interface for programming

Step	Activity
1	Connect DALI magic and PC with the enclosed USB cable.
(2)	<p>Connect the external 6V DC power supply to the DALI magic.</p> <p>The use of the external power supply is mandatory in case of more than 4 drivers connected to the DALI line, anyhow it is strongly recommended to always use the external power supply in order to improve the stability of the DALI communication.</p>
3	Connect the driver to mains and PE if the related terminal is available in the driver.
4	Connect the DALI® terminals of the DALI magic with the DALI® inputs of the driver(s).


Power on the driver



NOTE: most of the DALI LED drivers allow programming when supplied with a low voltage (e.g. 48V) in place of the mains voltage. For further details, please consult the LED driver's datasheets.

1.7 Preparing a driver with NFC interface for programming

Step	Activity
1	Connect a Programming Interface FEIG PRH101 or. FEIG CPR30 or FEIG MR102 to the PC with the enclosed USB cable.
2	Put the Programming interface close in contact with the NFC area of the driver (see logo) and do not move driver(s) and programming interface till the process is completed



Important Information:

Keep the driver powered OFF during programming via NFC unless otherwise indicated in the documentation of the driver.
 Keep both Programming interface antenna and driver with NFC close in contact during the complete programming process.

1.8 Software Installation

NOTE: Always read the "Release Notes" in the zip file before installing the SW.


To install the file you must have Windows administrator rights.

Extract the Tuner4TRONIC zip file into your local hard drive and then run "Install T4T.exe" located in that folder. **Running the Installer from inside the zip file will cause a faulty installation!**

Tuner4TRONIC Production can be launched from "Start" => "All Programs" => "OSRAM" => "Tuner4TRONIC" or by double-clicking the desktop icons.

2 Using T4T – Simple Current Programming Tool


2.1 Start Page




Read ECG Read data from driver connected by a programming interface (NFC, DALI). After successful reading data from driver, user will be directed to the programming page.

Tools	Open tools page
Help	Open help and about pages

2.2 Programming Page: Configuration




After reading data from a driver, driver name, EAN and IC base code is displayed in the header. User can enter any value within the min/max limits in the tab "Output current" (default: Output current value read from the driver). When programming the driver, LEDset will be deactivated and current setting mode will be switched to "Fixed Current Mode".



The driver can be protected with master key PW by ticking the check box next to the tab “Configuration Lock”. If check box is not ticked, driver will not be protected. The 4 digit password can be either entered manually or imported from an encrypted *.osrpwd file. Please check Tools/Create PW file for creating encrypted password files. Encrypted password from PW file will be displayed as “*”. Programming of protected drivers will be rejected, if Configuration Lock is not ticked or PW entered by the user does not matches PW from driver. Please note, that PW protection will be effective after first power cycle of the driver.

2.3 Programming Page: Programming





Header Driver data is displayed in the header. Programming drivers other than the driver type in the header will be rejected.

Configuration Data that will be programmed e.g. output current (mandatory) and password setting (optional) is displayed





Interface Selected programming interface is displayed

Box Programming Select “Box Programming” to program drivers in the box via NFC. Box programming can only be activated after having selected a programming interface that is suitable for box programming. If the driver is released for box programming, value in “Box size” is greater than “1”. Default setting loaded from production file and can be edited.

Detected Devices Shows the number of detected drivers (displayed after pressing programming buttons)

Start Programming	<p>Programming is started by pressing either</p> <ul style="list-style-type: none"> • Manual: Programming drivers in one single luminaire or one box • Auto: Starts programming drivers after being connected to the programming interface. Auto mode continues until batch size is reached. In box programming mode, programming starts when number of identified drivers match the box size
Status	Programming status is indicated by a symbol (see table Programming Status Indicators), a completion bar and text message
Results	<p>The number of passed and failed programmings is displayed. The same driver may be programmed multiple times. Only the last pass/fail will be counted and logged in the production file. The programming log can be viewed in the “Report” tab.</p>
	Press delete icon to delete the programming report in the production file and reset programming counter.
	Press edit icon to edit the batch size

Programming Status Indicators

	Waiting for Luminaire	Connect a luminaire/driver(s) to start/continue programming.
	Programming in progress	Do not remove the connected luminaire/drivers(s) until programming process is completed.
	PASS	Programming process has completed successfully. Remove luminaire/drivers(s)
	FAIL	Programming process has stopped by user or due to errors. Fix the problem then start programming again. Check message on screen for further details.

2.4 Report Page



ID	Device Name	Basic Code	Serial Number	Result
iEGG1	OTI DALI 20/220-240/500 NFC S	AM31177	12774601631086018873	Passed

For displaying list of parameters in production file select “Report” on the navigation bar.

Export Press export to create an html reporting file. Each line represents programming result one driver, luminaire or box

Print Press Print to print the report

2.5 Tools Page



Press Tools and select tools from drop down list

Tools / Settings Select "Programming" to select programming interface, set verify options and antenna power.
Select "General" to set language, sound and log options.

Tools / Create PW file Encrypt password and save in encrypted file. This allows user to create a password and forward to production department for programming drivers without disclosing the password file

Tools / Log Display log entries for debugging purposes

Tools / Check for updates Updates driver database file and software by reaching out to T4T cloud services.
If application is not connected to internet, please make sure that driver database file is updated manually by replacing "SimpleDatabase.dat" in the AppData folder ((typical in C:\Users\\AppData\Local\Tuner4TRONIC\T4TProduction4 software)

Save Save options on local computer and in production file where applicable. If settings have not been saved, any changes will be ignored when restarting T4T-P

Load Saved Load options from local computer and from production file where applicable

Reset Reset options to factory settings and to data from production file where applicable

OSRAM GmbH

Headquarters Germany:

Marcel-Breuer-Strasse 6
80807 Munich, Germany
Phone +49 89 6213-0
Fax +49 89 6213-2020
www.osram.com

Tuner4TRONIC support: T4Tsupport@osram.com

The OSRAM logo is displayed in a bold, orange, sans-serif font.